



T: 1300 764 971

sales@safeguardgroup.com.au
www.safeguardsafes.com.au

FRD 1HR Lock Instructions

Filing Cabinet Manual

WRONG TRY PENALTY

Three (3) consecutive invalid codes initiates five minute delay period.

LOW BATTERY WARNING

LOW BATTERY will appear in the LED readout. Safe will not open.

AUDIO SIGNAL

Audible CLICK indicates code entry is valid or accepted.

Triple signal indicates code is invalid or not accepted.

OPENING THE LOCK (factory set to *1234#)

- 1). Enter the valid FOUR (4) digit code. Start with * and end with #.
- 2). The lock will indicate a valid code entry with an audible CLICK.
- 3). Within four (4) seconds, lift handle to open drawer.
- 4). Pull drawer open.
- 5). Invalid code entry – Lock will signal three (3) times.

CHANGING MASTER CODE


ALWAYS PERFORM THIS OPERATION WITH THE DOOR OPEN

- 1). Open the drawer and press the "M" button.
- 2). Enter new code (four Digits) and press #, test code before closing the safe

ADDING AND CHANGING OTHER USER CODES

- 1). Enter *#master code(factory set 1234)#, "0 -EXIT" will appear on screen.
- 2). 1= Change code, 2 = Delete code.
- 3). Select user code to be changed or deleted using position number 2 – 5
- 4). To change, Enter user code and #, re-enter code and # screen reads SUCCESS or ERROR
If ERROR start from the beginning. OR Press 1 to delete user.

VIEW TRANSACTION LOG: Enter *#master code(factory set 1234)#, "0 -EXIT" will appear on screen press "8"



Delete Transaction Log

- 1). Enter *#master code(factory set 1234)#, "0 -EXIT" will appear on screen .
- 2). Press 9, select 1 for YES
- 3). Press "0" to DELETE LOG

CHANGING YOUR BATTERIES

- 1). Twist the keypad anticlockwise and unclip
Replace old batteries with four (4) alkaline "AA" cells, carefully replace keypad

We recommend that your safe is serviced at regular intervals, 12 – 18 months would be the optimum period if the safe is used daily. Failure to service your safe may eventuate in an expensive breakdown, to avoid this please have your safe checked.

To have your safe serviced, please contact your supplier to arrange a time to suit you.